

KHROMA

User Handbook

 **Nightingale**



3400 Series

nightingalechairs.com

Congratulations, this Khroma™ is yours.

Please read and understand this user handbook
before operating this office chair.



Using & Adjusting Your Khroma™



A PNEUMATIC HEIGHT ADJUSTMENT

To lower, lift the lever while seated. To raise, lift lever with your weight off the seat.



B TENSION KNOB

Turn knob clockwise to increase tension, turn counter-clockwise to decrease tension.



C MULTI POSITION TILT LOCK

Push lever forward to unlock, push lever back to lock.

Care Instructions

With regular care and maintenance, your Khroma™ will provide many years of superior performance and satisfaction. To maintain the quality of your Nightingale chair, please follow the cleaning instructions outlined here.

Mechanism

Once a year, lubricate using light sewing machine oil or similar product. (Spray with plastic straw attached to sprayer). NOTE: To prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

Plastic Parts

To clean, spray with a mild detergent and wipe off using a damp (water) cloth. Do not use abrasives or excessive amounts of cleaner.

Frame

Chrome frames can be cleaned by wiping with a damp cloth and any mild detergent.

*The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.

FOR MORE INFORMATION, PLEASE VISIT

www.nightingalechairs.com



Nightingale Corp.
T 1.800.363.8954
F 1.800.637.6784

www.nightingalechairs.com
info@nightingalechairs.com



RECYCLABLE