

ERGO-LEARN

User Handbook

 **Nightingale**



3280 Series

nightingalechairs.com

Congratulations, this Ergo-Learn™ is yours.

Please read and understand this user handbook
before operating this office chair.



3280



3280

Using & Adjusting Your Ergo-Learn™



A

Back Height Adjustment

Turn knob counter-clockwise to loosen, lift or lower chair back to desired lumbar position and re-tighten.



B

Back Angle Adjustment

While seated, pull paddle up, when desired angle is achieved push paddle down to lock.



C

Pneumatic Height Adjustment

To lower, lift paddle while seated. To raise, lift paddle with your weight off seat.



D

Infinite Seat Angle Lock

Lift up to determine seat angle. To lock seat in desired angle. push down.



E

Forward Tilt

Lean back in chair and roll or pull lever back for forward tilt, push or roll lever forward for straight position.



F

Seat Slider

Pull lever bar up to unlock, move seat to desired position, release lever to lock into position.



G

Arm Height

Push button up move arm up and down 4".



H

Adjustable Arm Width

To adjust arm width, loosen hand wheel (do not remove), move arm to desired position and re-tighten hand wheel.



I

Back Tension Knob

Turn clockwise to increase tension, turn counter-clockwise to decrease tension.

Care Instructions

With regular care and maintenance, your Ergo-Learn™ will provide many years of superior performance and satisfaction. To maintain the quality of your Nightingale product, please follow the cleaning instructions outlined here.

Mechanism

Oil sparingly moving parts once a year with light machine oil.
NOTE: to prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

Fabric

Clean with mild detergent and water applied with a clean damp cloth or sponge. Rinse with a damp (water) cloth and let dry. Never use hot water and avoid scrubbing. Use gentle movements.

Plastic Parts

To clean, spray with a mild detergent and wipe off using a damp (water) cloth. Do not use abrasives or excessive amounts of cleaner.

Frame

Powder coat frames can be cleaned by wiping with a damp cloth and any mild detergent.

*The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.

FOR MORE INFORMATION, PLEASE VISIT

www.nightingalechairs.com



Nightingale Corp.
T 1.800.363.8954
F 1.800.637.6784
www.nightingalechairs.com
info@nightingalechairs.com



RECYCLABLE